Evacuating and charging process (Domestic split air conditioner)

Category: Technologie
written by www.mbsm.pro | 21 May 2020




Evacuating and charging process (Domestic split air conditioner)

EVACUATING AND CHARGING PROCESS
(DOMESTIC SPLIT AIR CONDITIONER)

evacuating / vacuum (indoor & outdoor): close V4; open V1, V2, V3, V5 dan V6

vacuum (indoor): close V4, V5 & V6; open V1, V2 &V3

charging: close V2 &V3, open V1, V4, V5 & V6



Private Picture Copyright : WWW.MBSM.PRO