


Mbsm.pro, File, pdf, How to read the codes of maneurop compressors

Category: Files

written by www.mbsm.pro | 2 April 2022




Private Picture Copyright: WWW.MBSM.PRO

How to read the codes of maneurop compressors This model of maneurop compressors (MT&MTZ) is designed to work on a wide range of medium and high applications, especially the MT

model. It is specially designed to work on modern freons HFC

R407C- **R134a** -R404a-R507A

. It uses polyester oil PZ1 **60**. These compressors have the feature of protecting against liquid returning to the compressor as they have a wide pocket at the entrance to the intake line to evaporate the liquid before entering the piston cylinder. More than 16 models with different capacities starting from 1.84 to 16.57 cubic inches and working to feed 220v as well as 380v



- 1: 208-230 V / 1 ph / 60 Hz
- 3: 200-230 V / 3 ph / 60 Hz
- 4: 400 V / 3 ph / 50 Hz
- 460 V / 3 ph / 60 Hz
- 5: 230 V / 1 ph / 50 Hz
- 6: 230 V / 3 ph / 50 Hz
- 7: 500 V / 3 ph / 50 Hz
- 575 V / 3 ph / 60 Hz
- 9: 380 V / 3 ph / 60 Hz

- كود الإزاحة
- JK: 1.84 HL: 5.87
 - JC: 2.33 HM: 6.57
 - JE: 2.93 HN: 7.38
 - JF: 3.29 HP: 8.29
 - JG: 3.69 HS: 10.45
 - JH: 4.14 HU: 13.15
 - HJ: 4.65 HV: 14.76
 - HK: 5.23 HW: 16.57



Private Picture Copyright: WWW.MBSM.PRO

Mbsm_dot_pro_private_PDF_mbsmgroup_tn_3687_htmTélécharger