

Mbsmpro, Pdf, Convert LRA to Cooling Tons

Category: Pdf

written by www.mbsm.pro | 12 November 2025

How to Convert

LRA to TON

1 Phase

TOP COOLING SERVICE

Formula

$$\text{Ton} = \frac{\text{LRA}}{36}$$

$$\text{Ton} = \frac{54}{36}$$

TOP COOLING SERVICE

Ton = 1.5 Answer



picture copyright www.mbsmpro.com

picture copyright www.mbsmpro.com

Private Picture Copyright : WWW.MBSM.PRO

A Practical Guide: Convert LRA to Cooling Tons in HVAC Systems