

# Technical Troubleshooting: Automatic Washer Stops After Filling

Category: Global Electric

written by [www.mbsm.pro](http://www.mbsm.pro) | 30 January 2026

If your automatic washer fills with water but refuses to start the agitation or wash cycle, you are facing a common mechanical or electronic failure. This guide explores the primary culprits, including faulty lid switches, clogged pressure tubes, and failing drive motors, providing technical insights to help you diagnose and repair your appliance efficiently and safely.