

# Mbsm.pro, Compressor, Huaguang, Wanbao, ETZ95, 9.6 cm<sup>3</sup>, RSCR, 165 w, 563 BTU, r600a, LBP

Category: compressor

written by [www.mbsm.pro](http://www.mbsm.pro) | 24 March 2024



Mbsm.pro, Compressor, Huaguang, Wanbao, ETZ95, 9.6 cm<sup>3</sup>, RSCR, 165 w, 563 BTU,  
r600a, LBP

---

# Mbsm.pro, Panasonic, Compressor, DB66C10RAW5, RSCR, 1/5 hp, Lbp

Category: compressor

written by [www.mbsm.pro](http://www.mbsm.pro) | 24 March 2024



Private Picture Copyright : [WWW.MBSM.PRO](http://WWW.MBSM.PRO)

Mbsm.pro, Panasonic, Compressor, DB66C10RAW5, RSCR, 1/5 hp, Lbp

Mbsm.pro, Compressor, SAMSUNG, SK182H-L2U, 1/4 hp++, 1/3 hp -, 236 w, 806 BTu, Rscr, lbp, r134 a

Category: compressor

written by [www.mbsm.pro](http://www.mbsm.pro) | 24 March 2024



Private Picture Copyright : [WWW.MBSM.PRO](http://WWW.MBSM.PRO)

Mbsm.pro, Compressor, SAMSUNG, SK182H-L2U, 1/4 hp++, 1/3 hp -, 236 w, 806 BTu, Rscr, lbp, r134 a

---

Mbsm.pro, Compressor, HML190a, 1/4 hp, zel, Lambda, LBP, RSCR, Freezing compressor, R600a, 190 w, 163 kcal/h, run capacitor 3  $\mu$ F, aluminum wire

Category: compressor

written by [www.mbsm.pro](http://www.mbsm.pro) | 24 March 2024



Private Picture Copyright: WWW.MBSM.PRO

Mbsm.pro, Compressor, HML190a, 1/4 hp, zel, LBP, RSCR, Freezing compressor, R600a, 190 w, 163 kcal/h, run capacitor 3  $\mu$ F, aluminum wire

---

**Mbsm.pro, COMPRESOR, N1112dY, 1/6 Hp, N1116dY, 1/5 Hp, LBP, JIAXIPERA, R-600a, 4  $\mu$ F, RSCR, 220-240~/50**

Category: compressor

written by www.mbsm.pro | 24 March 2024



Private Picture Copyright : [WWW.MBSM.PRO](http://WWW.MBSM.PRO)

Mbsm.pro, COMPRESOR, N1112dY, 1/6 Hp, N1116dY, 1/5 Hp, LBP, JIAXIPERA, R-600a, 4  $\mu$ F, RSCR, 220-240~/50

---

Mbsm.pro, Compressor, LG, LX67LABM, Refrigeration, 1/5 HP, LBP, RSCR, 180 W, r134a

Category: compressor

written by [www.mbsm.pro](http://www.mbsm.pro) | 24 March 2024



Private Picture Copyright : [WWW.MBSM.PRO](http://WWW.MBSM.PRO)

Mbsm.pro, Compressor, LG, LX67LABM, Refrigeration, 1/5 HP, LBP, RSCR, 180 W

Mbsm.pro, LG, Compressor, cma075laem,  
1/4 Hp, rscr, 220-240 v, 50 hz, 185  
kcal/h, 734 btu/h, 215 w, r134a,  
Fixed Speed

Category: compressor

written by [www.mbsm.pro](http://www.mbsm.pro) | 24 March 2024

برچسب انرژی		
کمپرسور هرمتیک خانگی		انرژی
CMA075LAEM		
A B C D E F G		<b>A</b>
(W/W)	COP ضریب عملکرد	1.67
وات	ظرفیت برودتی کمپرسور	215.1
وات	توان ورودی کمپرسور	129

Private Picture Copyright : [WWW.MBSM.PRO](http://WWW.MBSM.PRO)

Mbsm.pro, LG, Compressor, cma075laem, 1/4 Hp, rscr, 220-240 v, 50 hz, 185 kcal/h, 734 btu/h, 215 w, r134a, Fixed Speed

# Mbsm.pro, Compressor, MGA51C84rLX, MGA51C68RPU, Panasonic compressor, M Series, Reciprocating Fixed Speed, 180 W, 1/5 Hp, RSCR, 220 V , r134a

Category: compressor

written by [www.mbsm.pro](http://www.mbsm.pro) | 24 March 2024



Private Picture Copyright : [WWW.MBSM.PRO](http://WWW.MBSM.PRO)

Mbsm.pro, Compressor, MGA51C84rLX, MGA51C68RPU, Panasonic compressor, M Series, Reciprocating Fixed Speed, 180 W, 1/5 Hp, RSCR, 220 V , r134a

---

# Mbsm.pro, Motor, compressor, type, RSIR, RSCR, CSIR, CSCR, PSC

Category: compressor

written by [www.mbsm.pro](http://www.mbsm.pro) | 24 March 2024

(1) RSIR

Resistance start induction run

(2) RSCR

Resistance start capacitor run

(3) CSIR

Capacitor start induction run

(4) CSCR/CSR

Capacitor start capacitor run

(5) PSC

Permanent split capacitor

(1) RSIR

Resistance start induction run

(2) RSCR

Resistance start capacitor run

(3) CSIR

Capacitor start induction run

(4) CSCR/CSR

Capacitor start capacitor run


(5) PSC

Permanent split capacitor

Private Picture Copyright : [WWW.MBSM.PRO](http://WWW.MBSM.PRO)

Private Picture Copyright : [WWW.MBSM.PRO](http://WWW.MBSM.PRO)

# Compressor Windings




Private Picture Copyright: WWW.MBSM.PRO




(1) RSIR  
Resistance start induction run

Private Picture Copyright: WWW.MBSM.PRO

# RSIR



Private Picture Copyright: WWW.MBSM.PRO



Private Picture Copyright: WWW.MBSM.PRO


# (2) RSCR Resistance start capacitor run

Private Picture Copyright : WWW.MBSM.PRO

## RSCR



Private Picture Copyright : WWW.MBSM.PRO



Private Picture Copyright: WWW.MBSM.PRO


# (3) CSIR Capacitor start induction run

Private Picture Copyright: WWW.MBSM.PRO

# CSIR



Private Picture Copyright: WWW.MBSM.PRO



Private Picture Copyright: WWW.MBSM.PRO




# (4) CSCR/CSR Capacitor start capacitor run

Private Picture Copyright: WWW.MBSM.PRO

## CSCR/CSR



Private Picture Copyright: WWW.MBSM.PRO



Private Picture Copyright: WWW.MBSM.PRO


# (5) PSC Permanent split capacitor

Private Picture Copyright: WWW.MBSM.PRO

# PSC



Private Picture Copyright: WWW.MBSM.PRO



Private Picture Copyright: WWW.MBSM.PRO

# Types of Electrical Motors, RSIR, CSIR, RSCR, CSR, PTC, NTC, LST, HST, MBP, HBP, LBP

Category: compressor, Files

written by [www.mbsm.pro](http://www.mbsm.pro) | 24 March 2024

## Types of Electrical Motors

### RSIR (Resistance Start-Induction Run)

LST motor. No capacitors. Auxiliary winding is disconnected after start up. Standard energy efficiency.

### CSIR (Capacitor Start-Induction Run)

HST motor. With starting capacitor. Auxiliary winding is disconnected after start up. Standard efficiency.

### RSCR (Resistance Start-Capacitor Run)

LST motor. With running capacitor. Auxiliary winding remains connected after start up. Used for high efficiency in small capacity compressors (particularly in household refrigeration)

### CSR (Capacitor Start and Run)

HST motor. Two capacitors (starting and running). Auxiliary winding remains connected after start up. Used for high efficiency in small compressors and for size reduced size motors in compressors with comparatively large displacements.



Private Picture Copyright : [WWW.MBSM.PRO](http://WWW.MBSM.PRO)

## Types of Electrical Motors

### RSIR (Resistance Start-Induction Run)

LST motor. No capacitors. Auxiliary winding is disconnected after start up. Standard energy efficiency.

### CSIR (Capacitor Start-Induction Run)

HST motor. With starting capacitor. Auxiliary winding is disconnected after start up. Standard efficiency.

### RSCR (Resistance Start-Capacitor Run)

LST motor. With running capacitor. Auxiliary winding remains connected after start up. Used for high efficiency in small capacity compressors (particularly in household refrigeration)

### CSR (Capacitor Start and Run)

HST motor. Two capacitors (starting and running). Auxiliary winding remains connected after start up. Used for high efficiency in small compressors and for size reduced size motors in compressors with comparatively large displacements

# Types of Electrical Motors

## **RSIR (Resistance Start-Induction Run)**

LST motor. No capacitors. Auxiliary winding is disconnected after start up. Standard energy efficiency.

## **CSIR (Capacitor Start-Induction Run)**

HST motor. With starting capacitor. Auxiliary winding is disconnected after start up. Standard efficiency.

## **RSCR (Resistance Start-Capacitor Run)**

LST motor. With running capacitor. Auxiliary winding remains connected after start up. Used for high efficiency in small capacity compressors (particularly in household refrigeration)

## **CSR (Capacitor Start and Run)**

HST motor. Two capacitors (starting and running). Auxiliary winding remains connected after start up. Used for high efficiency in small compressors and for size reduced size motors in compressors with comparatively large displacements.



Private Picture Copyright : [WWW.MBSM.PRO](http://WWW.MBSM.PRO)

Type of starting device

Current relay – (electromechanical). RSIR/CSIR motors and CSR low/medium-power motors with NTC (the NTC is connected in series with the starting capacitor and the main purpose is to reduce the current peaks in the relay contacts)

Potential relay – (electromechanical). CSR high-power motors.

PTC – (Positive Temperature Coefficient), the resistance increases with the temperature. Device only with RSIR or RSCR motors in the (Small L, B), L and P ranges.

NTC – (Negative Temperature Coefficient), the resistance decreases with the temperature. Used in some CSR in order to reduce dimensions and components.

## Type of starting device

**Current relay** – (electromechanical). RSIR/CSIR motors and CSR low/medium-power motors with NTC (the NTC is connected in series with the starting capacitor and the main purpose is to reduce the current peaks in the relay contacts)

**Potential relay** – (electromechanical). CSR high-power motors.

**PTC** – (Positive Temperature Coefficient), the resistance increases with the temperature. Device only with RSIR or RSCR motors in the (Small L, B), L and P ranges.

**NTC** – (Negative Temperature Coefficient), the resistance decreases with the temperature. Used in some CSR in order to reduce dimensions and components.



Private Picture Copyright : [WWW.MBSM.PRO](http://WWW.MBSM.PRO)

Type of torque

LST – Low Starting Torque – Systems with capillary tube or balanced pressures at start up.

HST – High Starting Torque – Systems with expansion valve or capillary tube, with unbalanced pressures at start up.


### Type of torque

**LST** – Low Starting Torque – Systems with capillary tube or balanced pressures at start up.

**HST** – High Starting Torque – Systems with expansion valve or capillary tube, with unbalanced pressures at start up.







Private Picture Copyright : [WWW.MBSM.PRO](http://WWW.MBSM.PRO)



Private Picture Copyright : [WWW.MBSM.PRO](http://WWW.MBSM.PRO)

Secop MBP compressors: evaporation pressures







-  Normal use: efficiency optimization & continuous operation
-  High load: continuous operation
-  Pull down: up to some hours after start or reloading



Private Picture Copyright : [WWW.MBSM.PRO](http://WWW.MBSM.PRO)

Secop LBP compressors: evaporation pressures



-  Normal use: efficiency optimization & continuous operation
-  High load: continuous operation
-  Pull down: short time operation (<60min.) after start or defrost



Private Picture Copyright : [WWW.MBSM.PRO](http://WWW.MBSM.PRO)